

# INSTRUCTIONS FOR INDIVIDUAL COMPONENTS

- **PC** projects the image from the computer mounted in the console. Be sure to log in to the computer using your college Username and Password. A wireless mouse for this computer is located in the basket on the upper right cabinet shelf.
  - **DVD/VCR** projects the image from either VHS tapes or DVDs loaded in the DVD/VCR unit mounted in the console. A remote control for the DVD/VCR unit is located in the basket on the upper right cabinet shelf.
  - **DOC CAM** projects the image from the full-color document camera mounted in console. Power and light switches for the document camera are located on the right side of the device.
  - **LAPTOP** will project the image from a laptop computer that is plugged into the console using the 15-pin VGA cable (for picture) and the mini (headphone jack) cable (for sound) available on top of the console. You may use the Ethernet cable which is also located on the top of the console surface.
- **A Wireless Mouse** for use with the installed PC is stored in the Accessories Drawer. Features are illustrated below:

